



**TECH
SERIES**

Voile Snow Saw Shovel



*Removable.
Attaches to
most adjustable
aluminum poles.*



VOILE-USA.COM • 801-973-8622



TECH SERIES

The user of this product is personally responsible for learning proper skiing/snowboarding/climbing techniques, avalanche awareness, and exercising good judgement.

LIFETIME GUARANTEE

The Voil Backcountry Avalanche Shovel is warranted to the original owner by the manufacturer against any defects in materials or workmanship for the lifetime of the shovel. Warranty service and replacement parts are available directly from Voil .

SAW BLADE INSTRUCTIONS

REMOVAL:

Hold handle and rotate blade counter clockwise

INSTALL:

A - Start at the pop pin and rotate 1/4 turn clockwise until tight.

B - Once installed, the blade should be perpendicular of the pop pin as shown. This allows pop button to operate on handle.



A



B

VOILE EQUIPMENT

2636 SOUTH 2700 WEST • SALT LAKE CITY, UT 84119

VOILE-USA.COM • 801-973-8622